



1. Apply the bulb by rotate
2. Adjust the cap in desirable position
3. Plug it in power to turn it on/ of by clicking the switch

